

PRODUCT: 440Express™ Micro-Pinhole Eliminator

**PART** 

NUMBER: 100440 16 fl. oz. 6 units per case

100444 4 fl. oz. Kit 1 unit per case 100439 12 pack 6 units per case

**DESCRIPTION:** 440Express Micro-Pinhole Eliminator is a quick fix for micro-pinholes that are hard to

identify prior to primer application. This 1K patent-pending technology is a high-solids polyester that is easy to apply and quick to dry. Testing has shown, when used properly,

will eliminate up to 90% of all rework caused by micro-pinholes. 440Express should be applied with part #439 Applicators.

APPROVED SUBSTRATES:

The following cured and sanded products:

Evercoat 2K Putties Evercoat Premium Fillers

Evercoat Quantum1™ 10:1 Products Cured and Sanded 2K Primer Surfacers

(When applying over a sanded 2K surfacer area must be re-primed and sanded or sealed before applying base coat)

## PREPARATION:



- Finish sand the repair with 180-grit or finer sandpaper.
- · Remove dust with compressed air.

## APPLICATION:



- Shake 440Express and apply a small amount on the applicator sponge or the repair area.
- Wipe 440Express over the entire repair area.

  Multiple applications may be necessary on larger repair areas.
- Continue to wipe until a light coat of 440Express has been applied. When applied properly, the repair area will still be visible through the light coat.
- Allow to dry 15 minutes and apply a primer surfacer according to paint manufacturer's recommendations.

If excess material builds up on the repair area, allow to dry 15-20 minutes, then lightly sand with 320 grit or finer sandpaper to remove any excess product prior to applying primer.

NOTE: When using waterborne primers, allow to dry for 15-20 minutes. Finish by scuffing with a gray or white scuff pad, then follow your waterborne coating manufacturers' recommendations.

**SAFETY &** 

**HANDLING:** Read all directions and warnings prior to using Evercoat products.

Safety Data Sheets can be found online at www.evercoat.com.

NOTES: 440Express is not designed to replace polyester glazing putties, or recommended for

use over conventional body filler.

For additional information on application techniques go to ITW Evercoat on YouTube.

**EVERC**