



ATD-8524

3-1/2 GALLON PARTS WASHER INSTRUCTION MANUAL

IMPORTANT SAFETY INSTRUCTIONS

1. Read all instructions before using this unit.
2. Care must be taken as burns can occur from touching hot parts.
3. Do not operate the equipment with a damaged cord or if the equipment has been dropped or damaged. Return the equipment to our service center for examination or mechanical adjustments or repair.
4. Do not let cord hang over edge of table, bench or counter or come in contact with hot manifolds or moving fan blades.
5. If an extension cord is necessary, a cord with a current rating equal to or more than that of the equipment should be used. Cords rated for less current than the equipment may overheat. Care should be taken to arrange the cord so that it will not be tripped over or pulled.
6. Always unplug equipment from electrical outlet when not in use. Never use the cord to pull the plug from the outlet. Grasp plug and pull to disconnect.
7. Let equipment cool completely before putting away. Loop cord loosely around equipment when storing.

8. To reduce the risk of fire, do not operate equipment in the vicinity of open containers of flammable liquids(gasoline).
9. Adequate ventilation should be provided when working on operating internal combustion engines.
- 10.Keep hair, loose clothing, fingers and all parts of body away from working parts.
- 11.To reduce the risk of electric shock, do not use on wet surfaces or expose to rain.
- 12.Use the equipment only as described in this manual. Use only manufacturer's recommended attachments.
- 13.**ALWAYS WEAR SAFETY GLASSES.** Everyday eyeglasses only have impact resistant lenses, they are **NOT** safety glasses.
- 14.**USE AQUEOUS BASED SOLVENTS THAT ARE RECOMMENDED FOR THIS PARTS WASHER ONLY**
15. **WARNING:** Do not fill parts washer above the top fluid level mark.


SAVE THESE INSTRUCTIONS

TECHNICAL SPECIFICATIONS:

Model	ATD-8524
Overall Dimensions	1-7/8"X1-3/8"X1"
Max Solvent Capacity	3.5 Gallons
Max Pump Output	2.91 gal/Min
Gross Weight	17 lbs



ATD-8524



ORDERING PART#	ITEM#	PART DESCRIPTION
PRT8524-101	101	TANK
PRT8524-102	102	LID
PRT8524-103	103	HD REMOVEABLE WORK SHELF
PRT8524-104	104	USE PRT8524-105
PRT8524-105	105	SAFETY PLATE (2 PCS)
PRT8524-106	106	PUMP
PRT8524-107	107	RIVET (5 PCS)
PRT8524-108	108	PUMP HOLDER
PRT8524-109	109	FLEXABLE METAL SPIGOT
PRT8524-110	110	PLASTIC PLATE, 4 PCS
PRT8524-111	111	SCREW, M5x30
PRT8524-112	112	NUT, M5
PRT8524-113	113	COVER
PRT8524-114	114	SCREW, M4x12 (3 PCS)
PRT8524-115	115	SWITCH COVER
PRT8524-116	116	SWITCH
PRT8524-117	117	STRAIN RELIEF
PRT8524-118	118	POWER CORD
PRT8525-28	119	SPIGOT