

PRODUCT FEATURES & APPLICATION



Dominion Sure Seal Ltd.

6175 Danville Road, Mississauga, Ontario, Canada L5T 2H7

TEL (905) 670-5411

FAX (905) 670-5174

Nylon Cup Brush 6"

TNBC (#208)

Color: Red

Description: Dominion Sure Seal's Nylon Cup Brush is specifically designed to work with all Dominion Sure Seal bed liners. Use Dominion Sure Seal Nylon Cup Brush with a standard buffer/polisher at 1000-1400 RPMS. The bristles on the cup brush are slightly angled to better reach into the ribs of the truck bed while sanding. The angle of the bristles also helps to keep you from applying too much direct pressure to the bristles which can cause easier sand throughs and cause the bristles to wear out prematurely. Dominion Sure Seal's Nylon Cup Brush works with all Dominion Sure Seal's bed liners and most competitive liners. This is a must have for all who are spraying in bed liners.

Features:

- Cuts sanding prep time by up to 50%
- Inexpensive tool – tremendous labor saver
- Provides an 80-120 grit scratch
- Works with a standard polisher/buffer with a 5/8" thread
- Operating RPM: 1000-1400 RPM.
- Can be used to prep up to 20-25 trucks

Application Instructions:

- 1) Attach Dominion Sure Seal Nylon Cup Brush to a variable speed buffer or polisher.
- 2) Clean the surface before using the Nylon Cup Brush with Dominion Sure Seal's Sure Solv or a good quality wax and grease remove. Wipe dry.
- 3) Plug your buffer/polisher in and set your speed to 1000-1400 RPMS and start sanding. Be careful to avoid sanding through the painted surface.
- 4) Once you have finished sanding everything you can with the Nylon Cup Brush, finish the areas you could not reach with 80 grit sandpaper by hand.
- 5) Blow out and re-clean with either Dominion Sure Seal Sure Solv or a good quality wax and grease remover.

Technical Properties:

Shelf Life:	N/A
Color:	Red
Approx Grit Scratch:	80-120
Abrasive:	Nylon Bristle

* If using the Nylon Cup Brush near areas or items you do not want sanded, Mask the area to try and protect the surface just in case you go over this area. Mask with masking tape or cloth tape.